

# Transvaginal Ultrasound: Imaging Considerations

**Page Links:** [Measurement Technique Summary](#), [Cervical Length Measurement](#), [Sources of Error](#), [Anatomic and Technical Pitfalls](#), [References](#)

## Measurement Technique Summary

How to Measure Cervical Length: Anatomic Landmarks	How to Measure Cervical Length
Bladder	Maternal bladder: empty
Fetal presentation	Place sterile cover over transvaginal ultrasound probe
Cervical canal	Insert probe into the vagina
Internal cervical os	Direct probe anteriorly to the fornix
External cervical os	Avoid measurement during uterine contraction
Vagina	


Above left. Note the appropriate anatomic landmarks for proper transvaginal ultrasound orientation.

Above right. Note the sequential steps for ultrasound performance. A review of image acquisition and technical performance for transvaginal ultrasound is also provided by these authors: [\[1\]](#)


How to Measure Cervical Length (Continued)	How to Measure Cervical Length (Continued)
<ol style="list-style-type: none"> <li>1. Adjust gain, zoom and focal zone to optimize image</li> <li>2. Obtain strict sagittal plane</li> <li>3. Image the entire cervical length</li> <li>4. Image cervical canal horizontally in the middle of the screen*</li> </ol> <p>*may not be possible if the cervix is directly anterior</p>	<ol style="list-style-type: none"> <li>5. Avoid excess pressure on the probe</li> <li>6. Withdraw the probe slightly when the canal is identified</li> <li>7. Place measurement cursors at the closing points of internal and external cervical os</li> <li>8. Measure the distance between cursors</li> </ol>

Above left and right. Follow the imaging sequence as listed above.


## Cervical Length Measurement




Above. When the mother is supine, the orientation of the vaginal ultrasound transducer probe in relationship to the position of the maternal feet and head is illustrated as well as the maternal orientation to posterior and anterior.



Above. Standard anatomic landmarks are the bladder, fetal presentation, cervical canal, internal cervical os, external cervical os, and vagina.




Above. Transvaginal ultrasound sagittal view of the cervix with the critical anatomic landmarks illustrated. The gain, zoom, and focal zone should be adjusted to optimize the image and a strict sagittal plane is necessary to image the entire cervix. The cervical canal is imaged horizontally in the middle of the screen, which may not be possible if the cervix is directly anterior.



Above. Once the cervical canal is identified, withdraw the probe slightly. Place the measurement cursors precisely at the closing points of the internal and external cervical os and measure the distance between them. For the internal os, a small triangle is often seen. Place the cursor at the apex of the triangle (the closing point). For the external os, follow the posterior cervical lip until the closing point is identified.


## Sources of Error

### 1. Visualize the entire cervix




Above. The entire cervix is not visualized in this example and the internal cervical os and external cervical os is not well defined. Although the cervical length is probably normal, this is a suboptimal image.

## 2. Accurate cursor placement




Above. In the image above, the caliper placement is not exact and the distal cervix is not completely visualized, which hampers the recognition of the external cervical os.

## 3. Excessive probe pressure




Above. Avoid excess pressure on the probe and confirm that the thickness of the anterior and posterior lip of the cervix is the same. In the above example, there is dissimilarity between the thickness of the anterior and posterior cervical lips.

#### 4. Lower uterine segment contractions



Above. Lower uterine segment contractions.



Above. Contractions may lead to an S-shaped canal and asymmetry of the anterior and posterior portions of the cervix.



#### 5. Spontaneous cervical changes



Above. Progressive cervical shortening may occur after transabdominal pressure in patients at risk for cervical incompetence. [\[2\]](#)

## Anatomic and Technical Pitfalls

In summary, a number of anatomic pitfalls are recognized and include: an underdeveloped lower uterine segment hampering the identification of the internal cervical os, focal myometrial contractions, spontaneous cervical change, and endocervical lesions such as polyps. [\[3\]](#) Technical pitfalls include incorrect interpretation due to vaginal probe orientation and due to cervical distortion by the probe.



Above. Transvaginal cervical length measurement training. A study shows that those with no prior training can adequately perform the transvaginal ultrasound exam after 18 consecutive ultrasound examinations, while those with experience required only 1 practice session to learn the technique. [4]

## References

### Related posts:

**Free CME: First Trimester Ultrasound (2.25 Credits)**

### AZ Topics

**Ebstein Anomaly: Imaging Considerations**

[Abstract: PMID: 17019742](#)

[\[back\]](#)

[Abstract: PMID: 9077619](#)

•

[\[back\]](#)

[Abstract: PMID: 10214824](#)

•

[\[back\]](#)

[Abstract: PMID: 17019742](#)

•

[\[back\]](#)